


Use the following example to become familiar with use of the Black Cat Exposure Guide.



Assume that the subject is in full sun (what we call AVERAGE SCENE (scene B) in the Scene Listing Chart inside), and that you are using 100 speed film and a 1/125 shutter speed.

1. Guide in hand, swing the movable triangle to the bottom (normal operating position) by pressing your thumb down on the triangle while moving the triangle to the bottom of the guide.

2. Locate the number 100 (FILM SPEED) on the outside of the movable dial.

3. Locate the letter B on the outer fixed circle and line up the B with the 100 (FILM SPEED). hold this setting in place.
4. Swing the triangle so the shutter speed points to 1/125 in the window.

5. Note that the aperture is 16.

Had you preferred to use a shutter speed of 1/1000, you would have swung the triangle to a shutter speed of 1/1000 and located your aperture (5.6) in the aperture window. You can choose any shutter speed or aperture combination.